Nek NRG1200

User's Manual Rel 1.0 GB

DTS
The Lighting Company

D.T.S. Illuminazione srl
Via Fagnano Selve 10/12/14
47843 Misano Adriatico (RN) ITALIA Tel +39 0541 611131 Fax +39 0541 611111 info@dts-lighting.it http://www.dts-lighting.it

Made in Italy

Le informazioni contenute in questo documento sono state attentamente redatte e controllate. Tuttavia non è assunta alcuna responsabilità per eventuali inesattezze. Tutti i diritti sono riservati e questo documento non può essere copiato, fotocopiato, riprodotto per intero o in parte senza previo consenso scritto della D.T.S .
D.T.S. si riserva il diritto di apportare senza preavviso cambiamenti e modifiche estetiche , funzionali o di design a ciascun proprio prodotto. D.T.S non assume alcuna responsabilità sull'uso o sull'applicazione dei prodotti o dei circuiti descritti.

The information contained in this publication has been carefully prepared and checked. However, no responsibility will be taken for any errors. All rights are reserved and this document cannot be copied, photocopied or reproduced, in part or completely, without prior written consent from D.T.S.
D.T.S. reserves the right to make any aesthetic, functional or design modifications to any of its products without prior notice. D.T.S. assumes no responsibility for the use or application of the products or circuits described herein.

Les informations contenues dans le présent manuel ont été rédigées et contrôlées avec le plus grand soin. Nous déclinons toutefois toute responsabilité en cas d'éventuelles inexactitudes. Tous droits réservés. Ce document ne peut être copié, photocopié ou reproduit, dans sa totalité ou partiellement, sans le consentement préalable de D.T.S.
D.T.S. se réserve le droit d'apporter toutes modifications et améliorations esthétiques, fonctionnelles ou de design, sans préavis, à chacun de ses produits. D.T.S. décline toute responsabilité sur l'utilisation ou sur l'application des produits ou des circuits décrits.

Las informaciones contenidas en este documento han sido cuidadosamente redactadas y controladas. Con todo, no se asume ninguna responsabilidad por eventuales inexactitudes. Todos los derechos han sido reservados y este documento no puede ser copiado, fotocopiado o reproducido, total o parcialmente, sin previa autorización escrita de D.T.S.
D.T.S. se reserva el derecho a aportar sin previo aviso cambios y modificaciones de carácter estético, funcional o de diseño a cada producto suyo. D.T.S. no se asume responsabilidad de ningún tipo sobre la utilización o sobre la aplicación de los productos o de los circuitos descritos.

INDEX:

1-SYMBOLS 4
2- GENERAL WARNING 4
3- GENERAL WARRANTY CONDITION 4
4- TECHNICAL FEATURES 5
5- TECHNICAL SPECIFICATIONS 7
6- ACCESSORIES 7
7- IMPORTANT SAFETY INFORMATION 8
7.1 Fire prevention
7.2 Prevention of electric shock
7.3 Safety
7.4 Level of protection against the penetration of solid and liquid objects
8- VOLTAGE AND FREQUENCY 9
9- INSTALLATION 9
9.1 Safety cable
9.2 Protection against liquids
9.3 Movement
9.4 Risk of fire
9.5 Forced ventilation
9.6 Ambient temperature
10- MAINS CONNECTION 11
10.1 Protection
11- DMX SIGNAL CONNECTION 12
11.1 DMX Addresses
11.2 Selecting the DMX address
12- FIRMWARE UPDATING 13
13- DISPLAY FUNCTIONS 14
14- PERIODIC CLEANING 23
15- PERIODIC CONTROLS 23
16- DMX PROTOCOL 24

1- SYMBOLS

Graphic symbols used on this manual

THIS SYMBOL INDICATES A HOT SURFACE

THIS SYMBOL INDICATES ELECTRIC SHOCK RISK

THIS SYMBOL INDICATES GENERAL RISK

THIS SYMBOL MEANS “DO NOT PLACE THE UNIT ON INFLAMMABLE SURFACES”

THIS SYMBOL INDICATES THE MINIMUM DISTANCE TO BE KEPT BETWEEN THE DEVICE AND THE LIT OBJECT

2- GENERAL WARNING

Read the instruction contained in this user manual carefully, as they give important information regarding safety during installation , use and maintenance.
The device is not for domestic use and must be installed by a qualified electrician or experienced person.
Always disconnect the device from the mains before maintenance.
The device must always be equipped with an efficient ground connection.

3- GENERAL WARRANTY CONDITIONS

The unit is guaranteed for 36 months from the date of purchase against manufacturing material defects.

4- TECHNICAL FEATURES

Overview
NICK NRG 1200 is the most efficient LED moving head wash light ever produced.
The exceptional brightness/consumption ratio makes NICK NRG 1200 a truly “green” fixture.
NICK NRG 1200 is equipped with 30 high-power Full Colour LEDs.
NICK NRG 1200 features two interchangeable lens fittings: Spot and Medium Flood – and ultra-fast silent Pan/Tilt.

Applications
NICK NRG 1200 is suitable for top professional applications, such as tours and special events.
NICK NRG 1200 is also available as NICK NRG 1200 CT FULLWHITE (30 Full White LEDs, 2700°K-6500°K).

Product codes

03.LDR008.FW12	NICK NRG 1200 CT FULLWHITE BLACK SPOT
03.LDR008.FW25	NICK NRG 1200 CT FULLWHITE BLACK MEDIUM
03.LDR008.F12	NICK NRG 1200 FULLCOLOR BLACK SPOT
03.LDR008.F25	NICK NRG 1200 FULLCOLOR BLACK MEDIUM

LED Technology
***** 30 Full Colour LEDs (RGBW)

Optical group
* Two interchangeable lenses sets: Spot and Medium Flood
* Uniform projection on surfaces

Colour generation
* 16 million colours (NICK NRG 1200 FULLCOLOR)
* Wide palette of pure uniform whites with variable linear colour temperature
  (2700°K – 8000°K NICK NRG 1200 FULLCOLOR)
  (2700°K – 6500°K NICK NRG 1200 CT FULLWHITE)

Interface / Control / Programming
***** Multi-function OLED graphic colour display + 4 soft keys: control / management / monitoring of the main parameters
* Controlled via DMX 512 and RDM standard digital communication protocols
* Wireless ready
* Ethernet ready
* Internal operating system updatable via D.T.S. RED BOX interface via “D.T.S. firmware upgrade utility” program on windows based PC

DMX
20 DMX channels

Pan & Tilt
* 16-bit movement resolution
* Ultra-fast movement: Pan 540° (2 sec.); Tilt 270° (1,2 sec.)
* Selectable speed ranges

Power supply
***** Electronic full-range AC 90-260 V 50 / 60 Hz
* Power consumption: 90 V – 3,7 A – 340 W ; 120 V – 2,83 A – 340 W ;
230 V – 1,47 A - 340 W ; 260 V – 1,3 A – 340 W

Connectors
* DMX: 4 XLR connectors (3-pole In and Out; 5-pole In and Out) by Neutrik;
* Power supply: POWERCONN In/Out connectors by Neutrik.

Operating ambient temperature
-10° / 40°

Weight
9,5 Kg

International certifications
Certification CE; LED Class: Class 2 LED product

5- TECHNICAL SPECIFICATIONS

Dimensions

Packaging Dimensions (LxWxH)

530 x 430 x 414 mm

Weight: 12 Kg



Unit Dimensions (LxWxH)

369x218x497 mm

Weight: 9,5 Kg



6- ACCESSORIES

As standard

- 1 x POWERCONN male cable connector (cod. 0520P014)
- 1 x XLR 5 Pins male cable connector (cod. 0508B028)
- 1 x XLR 5 Pins female cable connector (cod. 0508B027)
- “C” Clamp GQUICK with “Fast Lock” connection 1/4 turn (cod. 0521A014)
- User’s manual

Optional (on request)

Flight case

- Professional Flight case for 4 units; compartment for accessories, swivel wheels, cover with hinges with-stay, dishes on cover for piling, 8 handles (2 eachside) (cod. 0521C051.1)

Wireless DMX receiver retrofit

- Wireless DMX Receiver Card with INDOOR IP20 omnidirectional 2dBi antenna included (cod.03.LA.126)

Clamps / safety wires

- “C” Clamp G60 black (max. load 50Kg) (cod. 0521A004)
- “C” Clamp G60 chrome (max. load. 50Kg) (cod. 0521A004.20)
- “C” Clamp GQUICK with “Fast Lock” connection 1/4 turn (max. load. 80Kg) (cod. 0521A014)
- “C” Clamp G100 black / professional (max. load. 200Kg) (cod. 0521A015)
- Omega clamp with “Fast Lock” connection 1⁄4 turn 1 couple (2 pieces) (Cod. 02K00467)
- Safety wire (3mm x 60 cm), ring spring catch, max. capacity load 60Kg (cod. 0521A010)

7- IMPORTANT SAFETY INFORMATION

7.1 Fire prevention:

-Never locate the fixture on any flammable surface.
-Minimum distance from flammable materials: 1 MT.
-Minimum distance from the closest illuminable surface: 0,5 MT. 

-Replace any blown or damaged fuses only with those of identical value.
Refer to the wiring diagram if there is any doubt.
-Connect the projector to mains power via a thermal magnetic circuit breaker.

7.2 Prevention of electric shock:

-High voltage is present inside the unit. Unplug the unit prior to performing any function which involves touching the inside of the moving head.
-The level of technology inherent in the NICK NRG 1200 requires the assistance of specialised personnel for all servicing.
Please refer to an authorised D.T.S. service centre.
-A good earth connection is essential for proper functioning of the projector.
-Never connect the unit without proper earth connection.
-The fixture should be located in places with a good air ventilation.

7.3 Safety:

-The projector should always be installed with bolts, clamps and other tools that are capable of supporting the weight of the unit.
-Always use a second safety cable to sustain the weight of the unit in case of the failure of the main fixing point.
-The external surface of the unit, at various points, may exceed 70°C. Never handle the unit until at least 10 minutes have elapsed since the projector was turned off.
-Never install the fixture in an enclosed area lacking sufficient air flow.
The ambient temperature should not exceed 40°C.

7.4 Level of protection against the penetration of solid and liquid objects:

-The projector is classified as an ordinary appliance and its protection level against the penetration of solid and liquid objects is IP 20.

8- VOLTAGE AND FREQUENCY

The NICK NRG 1200 can operate at 90-260 VOLT 50 or 60 Hz.

9- INSTALLATION

NICK NRG 1200 may be either floor or ceiling mounted.
For floor mounting installations, the NICK NRG 1200 is supplied with four rubber mounting feet on the base.
For ceiling mounted installations, we reccomend the use of appropriate clamps to fix the unit to the mounting surface.
The supporting structure from which the unit is hung should be capable of bearing the weight of the unit, as should any clamps used to hung it. The structure should also be sufficiently rigid so as not to move or shake whilst the NICK NRG 1200 is moving.
Four 1/4 turn Fast Locks connections placed in the base of the unit allow to hang the NICK NRG 1200 by using the Fast Lock “C” clamps provided in the box.

9.1- Safety cable

We recommend the use of a safety cable or chain connected to the NICK NRG 1200 and to the suspension truss in order to avoid the fixture accidentally falling should the main fixing point fail.
Make sure that the iron cable or chain can bear the weight of the entire unit.
You may attach the safety chain/cord to the attachment point (A) located on the base of the fixture, as shown in the picture below.



9.2 Protection against liquids

The projector contains electric and electronic components which should under no circumstances come into contact with oil, water or any other liquid.
The proper unit functioning would be compromised should this occur.

9.3- Movement

Ultra-fast movement: Pan 540° (2,0 sec.); Tilt 270° (1,2 sec.)

WARNING

Do not place any object in the path of the projector's movement

9.4- Risk of fire

Each fixture produces heat and must be installed in a well-ventilated place.
The minimum recommended distance from flammable material is 1 MT.

Minimum distance from the object being illuminated is 0,5 MT.

9.5- Forced ventilation

You will note, on inspection, that the unit features various air inlets and cooling fans. These should, under no circumstances, be blocked or obstructed whilst the projector is in operation. Doing so could cause the fixture to seriously overheat thereby compromising its proper operation.

9.6- Ambient temperature

The projector should never be installed in places that lack a constant air flow.
The ambient temperature should NOT exceed 40°C.

10- MAINS CONNECTION

NICK NRG 1200 operate at 90-260 VOLT 50-60 Hz.
Prior to connecting the unit to your mains supply, ensure that the model in your possession correctly matches the mains supply available.
For connection purposes, ensure that your plug is capable of supporting 2 amps at 230V, or 5 amps at 90 V.
Strict adherence to regulatory norms is strongly recommended.

MAINS AC OUTPUT 90 – 260 V 50 / 60 Hz (16A Max)
MAX 10 NICK NRG 1200 UNITS @ 230V
MAX 5 NICK NRG 1200 UNITS @ 120V



Cod. 03.LDR008.FW12
Cod. 03.LDR008.FW25

Cod. 03.LDR008.F12
Cod. 03.LDR008.F25

MAINS AC INPUT 90 – 260 V 50 / 60 Hz

Wireless DMX Receiver Retrofit (Cod. 03.LA.126)

FUSE 5A T 5X20

10.1- Protection

The use of a thermal magnetic circuit breaker is recommended for each NICK NRG 1200.

11- DMX SIGNAL CONNECTION

The unit operates using the digital DMX 512 (1990) signal.
Connection between the mixer and the projector or between projectors must be carried out using a two pair screened ø 0.5 mm cable and a XLR 5 or 3 pins connector.
Ensure that the conductors do not touch each other.
Do not connect the cable ground to the XLR chassy.
The plug housing must be isolated. Connect the mixer signal to the DMX IN projector plug and connect it to the next projector by connecting the DMX OUT plug on the first projector to the DMX IN plug of the second one.
This way, all the projectors are cascade connected.
NB. If the display showing the DMX address flashes, then one of the following errors has occurred:

- DMX signal not present
- DMX address not valid
- DMX reception problem



For Installations where long distance DMX cable connections are needed, we suggest to use a DMX terminator.
The DMX terminator is a male XLR 3-5 pins connector with a 120 ohm resistor between pin 2 and 3.
The DMX terminator must be plugged into the last unit (DMX out panel connector) of the DMX line.



PLACE A 120 OHM RESISTOR BETWEEN PIN 2 AND 3 OF A MALE XRL CONNECTOR AND PLUG IT INTO THE DMX OUT PANEL CONNECTOR OF THE LAST UNIT CONNECTED TO THE DMX LINE



11.1-DMX Addresses

NICK NRG 1200 can be controlled with 20 DMX channels.
In order to use the unit in 20 channels, set the following addresses on the mixer:

Projector 1	A001	
Projector 2	A021	If you want to select the next projector, just add “20”
Projector 3	A041	
…..	A….	
projector 6	A101	

11.2-Selecting the DMX address

1) Press the UP-DOWN key until you reach the required DMX channel. The numbers on the display will start to flash (but the new DMX address hasn't yet been set).
2) Press ENTER to confirm your selection. The numbers on the display will stop flashing and the projector is now setted to the new DMX address.

TRICKS:
if you keep pushed the UP or DOWN keys, the channels are calculated more quickly and you get a faster selection.

12- FIRMWARE UPDATING

Warning:
This procedure require a base knowledge of computer applications and Windows Hyperterminal program. **Please refer to an authorised D.T.S. service centre.**

To update the software version of the NICK NRG 1200 you need:
D.T.S. RED BOX interface (D.T.S. Code: 03.LA.008).
USB-DMX Driver for the D.T.S. RED BOX interface.
D.T.S. Firmware upgrade utility program.
(The driver and the installation procedure are available in our web site www.dts-lighting.it)

Updating the software version.
Please follow the procedure below to perform the update:

1. Install the D.T.S. RED BOX USB-DMX driver on the PC you will use to update the unit software.
2. Connect the D.T.S. RED BOX interface to the PC by using a USB cable.
3. Connect the D.T.S. RED BOX interface to the fixture by using a DMX cable.
4. Download the new software version into the unit by using D.T.S. Firmware upgrade utility program.

13- DISPLAY FUNCTIONS



WIRELESS DMX
RECEIVER
RETROFIT
03.LA.126



DISPLAY FUNCTIONS

The NICK NRG 1200 display panel shows all the available functions . Using these functions, it is possible to change some of the parameters and add some functions. Changing the D.T.S. setting can vary the functions of the unit so that it does not respond to the DMX 512 used to control it. Carefully follow the instructions below before carrying out any variations or selections.
NOTE: the symbol ☞ shows which key has to be pushed to obtain the desired function.

13- DISPLAY FUNCTIONS

Software version 1.04

Menu Up-Down Display ENTER Up-Down

DISPLAY POSITION / STAND BY

Display Position:
Reverses display's reading depending on the mounting position
(on the ground or suspended).

Display Standby:
To turn off the display (after 5 seconds) or leave it always on.



Display Position
ON THE GROUND (Default)
SUSPENDED

ENTER

ENTER

Display Standby
OFF = Display Standby disabled (Default)
ON = Display goes OFF after 5 seconds

Menu Up-Down DMX Set ENTER Up-Down

DMX MODE / MACRO
DMX Mode
20 channels



DMX Mode
20 channels

ENTER

MACRO
Macro Mode:
STD = Standard (Default)
EXT = Extended; enable rainbow effects on Macro channel (DMX ch 16)



MACRO
STD = Standard mode enabled (Default)
EXT = Extended; enable rainbow effects on Macro channel (DMX ch 16)

13- DISPLAY FUNCTIONS

Menu Up-Down LED ENTER Up-Down



RED Min default = 0
RED Max default = 100

ENTER

RGBA MINIMUM VALUES
This menu allow to select the minimum levels for Red, Green, Blue and Amber/White



BLUE Min default = 0
BLUE Max default = 100

RGBA MAXIMUM VALUES
This menu allow to select the maximum levels for Red, Green, Blue and Amber/White
These settings have priority on Master Dimmer (DMX channel 9)



GREEN Min default = 0
GREEN Max default = 100

SMOOTH VALUE
This menu allow to select the value of the delay (in milliseconds) for RGBA and Dimmer channels reaction to DMX or Program variation.
4 = 25 ms delay (Fast response)
20 = 250 ms delay (Slow response)



AMBER Min default = 0
AMBER Max default = 100



SMOOTH
Range = Off – 20
Default = 4

13- DISPLAY FUNCTIONS

GAMMA CORRECTION
This menu allow to select between Linear current output or Quadratic current output for LEDs
Default = Quadratic



GAMMA CORRECTION
Linear = Linear current output
Quadratic = Linear light output
(default)

ENTER

OUTPUT FREQUENCY
This menu allow to adjust the PWM frequency value (Hz) in order to reduce flickering in the process of your camera recordings



OUTPUT FREQUENCY
Range = 610 Hz – 10KHz
Default = 610 Hz

BOOST DRIVING
This menu allow to increase the LED's current from 350 mA to 500 mA



BOOST
With BOOST active, the LEDs current is set to 500 Ma (30% more gain)
Default = Enabled

Menu Up-Down AUTO ENTER Up-Down

ENTER

By setting all the units connected to the MASTER to DMX address 1, them will be synchronized with the Master unit following the chase selected on it including TIME, WAIT, Pan and Tilt position of the MASTER unit.

AUTOMATIC MODE
Automatic demo game without DMX controller

STEP 01/16
Chase with 16 steps previously created in REC MODE
Speed time, Wait time, Dimmer, Pan and Tilt values selectable by user.

PERSONAL COLOURS
RGBA, Dimmer, Shutter, Pan and Tilt values selectable by user.



RAINBOW
Rainbow colours effect.
Speed time, Dimmer, Shutter, Pan and Tilt values selectable by user.

13- DISPLAY FUNCTIONS

FIXED COLOURS
Sixteen Colour Macros as on “MACRO” channel.
Dimmer, Shutter, Pan and Tilt values selectable by user.

WHITE MACROS
Sixteen macros for White color (from 2700 ° K to 8000 ° K for NICK NRG 1200 FULLCOLOR; from 2700 ° K to 6500 ° K for NICK NRG 1200 CT FULLWHITE).
Dimmer, Shutter, Pan and Tilt values selectable by user.



By setting all the units connected to the MASTER to DMX address 1, them will be synchronized with the Master unit following the chase selected on it including TIME, WAIT, Pan and Tilt position of the MASTER unit.

ENTER

Menu Up-Down SLAVE ENTER Up-Down

SLAVE MODE SETTING
This menu allow to set the NICK NRG 1200 as slave unit.
DMX signal must be present from MASTER unit (set in AUTO MODE) in order to ran the units in SLAVE mode.
By setting all the SLAVE units connected to the MASTER, to DMX address 1, them will be synchronized with the Master unit following the chase selected on it, but running their own Pan and Tilt position.





The SLAVE unit receive DMX signal from the MASTER unit.
By setting all the SLAVE units connected to the MASTER, to DMX address 1, them will be synchronized with the Master unit following the chase selected on it, but running their own Pan and Tilt position.

ENTER

13- DISPLAY FUNCTIONS

Menu Up-Down WIRELESS ENTER Up-Down

WIRELESS DMX SYSTEM DISABLED (Default) ENTER

WIRELESS DMX
Wieless DMX enabled / disabled.
By activating WDMX MODE, it will be possible to control Nick NRG 1200 via D.T.S. ANTENNA Wireless DMX Transmitter (cod. 03.E1271).

Wireless DMX Receiver Kit (Cod. 03.LA.126) on NICK NRG 1200 is available on request.

WIRELESS DMX SYSTEM ENABLED ENTER

UNLINK = LOG OUT ENTER

Logging on NICK NRG 1200 (WIRELESS DMX must be enabled on the unit).

To log on the NICK NRG 1200 in the WIRELESS system simply press and quickly release the function button on the transmitter .
The transmitter will start flashing rapidly red/green scanning for new free receivers / NICK NRG 1200 units. When a NICK NRG 1200 logs on to the transmitter the LINK green light on transmitter starts to flash rapidly.
After approximately 10 seconds the transmitter will jump back to normal mode and continue transmitting data. The NICK NRG 1200 now try to synchronize to the transmitter.
When synchronized to the transmitter, 2 different modes are possible:
1. Antenna transmitter has detected and transmits a DMX signal, in this mode a solid green light is seen on the transmitter and solid display is seen on NICK NRG 1200.
2. No DMX signal connected, the Antenna transmitter will flash red/green; display blinking on NICK NRG 1200.

To log off NICK NRG 1200 from a transmitter simply select UNLINK function under WIRELESS DMX MENU and press ENTER.
When NICK NRG 1200 is logged off the display is blinking, meaning its available for log in on a new transmitter.

Logging out a NICK NRG 1200.
Select UNLINK function under WIRELESS DMX MENU and press ENTER.
When NICK NRG 1200 is logged off the display is blinking, meaning its available for log in on a new transmitter.

Logging out all NICK NRG 1200 linked to a transmitter.
Press and hold the function button of the transmitter for about 3 seconds. When the display is blinking on NICK NRG 1200, it mean that the units are logged out.

Transmitter, Status LED.
Flashing red/green, no dmx connected.
Solid green, dmx signal detected and transmitted.
Fast flashing red/green, log in mode (every free NICK NRG 1200 unit, not logged in to any other transmitter, will be logged on)

NICK NRG 1200 Status.
Display blinking, not logged on to a transmitter (free).
Solid display, logged on to a transmitter and receiving dmx data.

13- DISPLAY FUNCTIONS

Menu Up-Down EMERGENCY ENTER Up-Down

EMERGENCY
Emergency operating mode.
By setting Emergency mode, it will be possible to select one of the 16 preprogrammed WHITE cues that will then ran if DMX signal is missing or not available.
Useful for Emergency EXIT illumination on public areas.
Dimmer level and Pan&Tilt values selectable by user.

EMERGENCY
Disabled = Default

ENTER

EMERGENCY
Enabled

WHITE (1-16)
Default = WHITE 1



DIMMER
Default = 255



PAN
Default = 128

TILT
Default = 128

13- DISPLAY FUNCTIONS

Menu Up-Down DEFAULT SET ENTER Up-Down

DEFAULT SETTINGS
To restore default settings



ENTER



Menu Up-Down TEMPER. °C ENTER

TEMPERATURE
Unit temperature



Menu Up-Down TIME ENTER Up-Down

LIFE TIME
This menu show the total UNIT life time and the RGBA life time



ENTER







13- DISPLAY FUNCTIONS

Menu Up-Down SYSTEM ENTER Up-Down

PAN INVERSION / TILT INVERSION /
PAN SPEED / TILT SPEED /
FAN MAX SPEED / RESET BY DMX /
MOTORS FIRMWARE UPGRADE.

PAN INVERSION
This menu allows to set the Pan movement. Normal or Reversed.

TILT INVERTION
This menu allows to set the Tilt movement. Normal or Reversed.

PAN SPEED
Pan Speed control (1-8)

TILT SPEED
Tilt Speed control (1-8)

FAN MAX SPEED
This menu' allow to select the internal fans speed.

RESET BY DMX
This menu' allow to enable / disable the Motors reset control (Pan&Tilt) via DMX.

MOTORS FIRMWARE UPGRADE
This menu' allow to upgrade the firmware for Pan&Tilt circuit boards.



PAN INVERSION
Default = NORM

ENTER



TILT INVERSION
Default = NORM



PAN SPEED CONTROL
Default = 4



TILT SPEED CONTROL
Default = 4



FAN MAX SPEED
50% - 100%
Default = 100%



RESET BY DMX
Enable: Motors reset enabled via DMX (Default)
Disabled: Motors reset disabled via DMX
Now: Instant motors reset.



MOTORS FIRMWARE UPGRADE
Pan&Tilt circuit boards firmware upgrade.

13- DISPLAY FUNCTIONS

Menu Up-Down SOFTWARE ENTER Up-Down

SOFTWARE
LEDs circuit board software,
MOTORS circuit boards software
(Pan&Tilt)

LEDs CIRCUIT BOARD SOFTWARE ENTER



MOTORS CIRCUIT BOARDS SOFTWARE
(PAN&TILT)

14- PERIODIC CLEANING

Front lenses Glass

The dust can reduce the luminous output substantially.
Regularly clean the front lenses glass using a soft cotton cloth, dampened with a specialist glasses cleaning solution.

Fans and air passages

The fans and air passages must be cleaned approximately every 6 weeks.
This periodic cleaning will depend of course, on the conditions in which the projector is operating.
Suitable instruments for performing this type of maintenance are a brush and a common vacuum cleaner or an air compressor.
If necessary, clean the fans and air passages more frequently.

15- PERIODIC CONTROLS

Mechanical parts

Periodically check all mechanical parts and the gaskets, replacing them if necessary.

Electrical components

Check all electrical components for correct earthing and proper attachment of all connectors, refastening if necessary.

Attention: Disconnect mains power prior to removing the projector housing.



Fuse replacement

Locate the fuse, which protect the electronics, in the base of the NICK NRG 1200. Using a multimeter, test the condition of the fuse, replacing it with one of equivalent type if necessary.

Attention: Disconnect mains power prior to removing the projector housing.

16- DMX PROTOCOL

20 CHANNELS MODE

1 PAN msb 540°
2 PAN lsb
3 TILT msb 270°
4 TILT lsb
5 SPEED MOVEMENT
6 NO FUNCTION
7 NO FUNCTION
8 SHUTTER
9 DIMMER
10 RED
11 GREEN
12 BLUE
13 WHITE
14 WHITE PREPROGRAMMED
15 CTC
16 MACRO
17 FUNCTION (Recall, Create and Store the Custom white)
18 NO FUNCTION
19 NO FUNCTION
20 RESET

DMX CHANNEL	1	Parameter: **PAN msb**

DMX CHANNEL	2	Parameter: **PAN lsb**

DMX CHANNEL	3	Parameter: **TILT msb**

DMX CHANNEL	4	Parameter: **TILT lsb**

DMX CHANNEL	5	Parameter: **SPEED MOVEMENT**

DMX range Value	Mid Point DMX value	Move Range (degrees)	Mode	Option	Function
000-010					**Standard**
011-025					**Fast movement**
026-127					**Vector mode from fast to slow**
128-247					**Variable time reaction to DMX signal (fast to slow)**
248-255					**Slow reaction time to DMX signal**

DMX CHANNEL	6	Parameter: **NO FUNCTION**

DMX range Value	Mid Point DMX value	Move Range (degrees)	Mode	Option	Function
000-255					**NO FUNCTION**

DMX CHANNEL	7	Parameter: **NO FUNCTION**

DMX range Value	Mid Point DMX value	Move Range (degrees)	Mode	Option	Function
000-255					**NO FUNCTION**

DMX CHANNEL	8	Parameter: **SHUTTER**

DMX range Value	Mid Point DMX value	Move Range (degrees)	Mode	Option	Function
000-009					**Black-out**
010-019					**Open**
020-029					**Black-out**
030-119					**Strobe (from 3.27 s to 30 ms)**
120-149					**Pulse up (from 42.6 s to 120 ms)**
150-179					**Pulse down (from 42.6 s to 120 ms)**
180-204					**Random strobe (Dimmer, Red, Green, Blue, Amber channels active)**
205-229					**Full independent Random Strobe (Dimmer, Red, Green, Blue, Amber channels disabled)**
230-255					**Open**

DMX CHANNEL	9	Parameter: **DIMMER**

DMX range Value	Mid Point DMX value	Move Range (degrees)	Mode	Option	Function
000-007					**Black-out**
008-255					**Proportional dimmer**

DMX CHANNEL	10	Parameter: **RED**

DMX range Value	Mid Point DMX value	Move Range (degrees)	Mode	Option	Function
000-255					**Proportional colour**

DMX CHANNEL	11	Parameter: **GREEN**

DMX range Value	Mid Point DMX value	Move Range (degrees)	Mode	Option	Function
000-255					**Proportional colour**

DMX CHANNEL	12	Parameter: **BLUE**

DMX range Value	Mid Point DMX value	Move Range (degrees)	Mode	Option	Function
000-255					**Proportional colour**

DMX CHANNEL	13	Parameter: **WHITE**

DMX range Value	Mid Point DMX value	Move Range (degrees)	Mode	Option	Function
000-255					**Proportional colour**

DMX CHANNEL	14	Parameter: **WHITE PREPROGRAMMED (White at diff. colour temperature)**

DMX range Value	Mid Point DMX value	Move Range (degrees)	Mode	Option	Function
000-055	**23**				**No Function**
056-105	**80**				**Full (Red-Green-Blue at Full)**
106-155	**130**				**White DTS**
156-205	**180**				**Custom White Create (RGB levels selectable by DMX)**
206-255	**230**				**White CTC (Channel 15 CTC enabled)**

DMX CHANNEL	15	Parameter: **CTC (Colour Temperature Correction)**

DMX range Value	Mid Point DMX value	Move Range (degrees)	Mode	Option	Function
IF CHANNEL 14 WHITE PREPROGRAMMED = WHITE CTC (DMX range value 206 – 255)					
000-255					**Linear control temperature correction. NICK NRG 1200 FULLCOLOR: 0 = 2700°K / 255 = 8000°K. NICK NRG 1200 CT FULLWHITE: 0 = 2700°K / 255 = 6500°K**

DMX CHANNEL	16	Parameter: **COLOUR MACROS**

IF: Menu Up-Down **DMX SET** ENTER Up-Down **MACRO** ENTER Up-Down **STD** ENTER **(Please refer to page 15 for details)**

000-014					**No Function**
015-029					**Macro 1**
030-044					**Macro 2**
045-059					**Macro 3**
060-074					**Macro 4**
075-089					**Macro 5**
090-104					**Macro 6**
105-119					**Macro 7**
120-134					**Macro 8**
135-149					**Macro 9**
150-164					**Macro 10**
165-179					**Macro 11**
180-194					**Macro 12**
195-209					**Macro 13**
210-225					**Macro 14**
226-239					**Macro 15**
240-255					**Macro 16**

DMX CHANNEL	16	Parameter: **COLOUR MACROS**

IF: Menu Up-Down **DMX SET** ENTER Up-Down **MACRO** ENTER Up-Down **EXT** ENTER **(Please refer to page 15 for details)**

000-014					**No Function**
015-024					**Macro 1**
025-034					**Macro 2**
035-044					**Macro 3**
045-054					**Macro 4**
055-064					**Macro 5**
065-074					**Macro 6**
075-084					**Macro 7**
085-094					**Macro 8**
095-104					**Macro 9**
105-114					**Macro 10**
115-124					**Macro 11**
125-134					**Macro 12**
135-144					**Macro 13**
145-154					**Macro 14**
155-164					**Macro 15**
165-174					**Macro 16**
175-184					**Rainbow Speed 1 (6 Sec.)**
185-194					**Rainbow Speed 2 (15 Sec.)**
195-204					**Rainbow Speed 3 (30 Sec.)**
205-214					**Rainbow Speed 4 (45 Sec.)**
215-224					**Rainbow Speed 5 (60 Sec.)**
225-234					**Rainbow Speed 6 (120 Sec.)**
235-244					**Rainbow Speed 7 (150 Sec.)**
245-255					**Rainbow Speed 8 (180 Sec.)**

DMX CHANNEL	17	Parameter: **FUNCTIONS (Recall, Create and Store the Custom white)**

DMX range Value	Mid Point DMX value	Move Range (degrees)	Mode	Option	Function
IF CHANNEL 14 WHITE PREPROGRAMMED = DMX range value 156 – 205)					
000-079					**Custom White Recall**
080-160					**Custom White Create (Enable Custom White Creation)**
161-255					**Custom White Store (Store the Custom White created)**

DMX CHANNEL	18	Parameter: **NO FUNCTION**

DMX range Value	Mid Point DMX value	Move Range (degrees)	Mode	Option	Function
000-255					**NO FUNCTION**

DMX CHANNEL	19	Parameter: **NO FUNCTION**

DMX range Value	Mid Point DMX value	Move Range (degrees)	Mode	Option	Function
000-255					**NO FUNCTION**

DMX CHANNEL	20	Parameter: **RESET**

DMX range Value	Mid Point DMX value	Move Range (degrees)	Mode	Option	Function
000-015					**No Effect**
016-255					**Total Reset (activation after 3 sec.)**

NOTES

NOTES

NOTES

The information contained in this publication has been carefully prepared and checked. However, no responsibility will be taken for any errors. All rights are reserved and this document cannot be copied, photocopied or reproduced, in part or completely, without prior written consent from D.T.S.
D.T.S. reserves the right to make any aesthetic, functional or design modifications to any of its products without prior notice. D.T.S. assumes no responsibility for the use or application of the products or circuits described herein.

MADE IN ITALY CE

DTS

The Lighting Company

ISO 9001:2008

D.T.S. quality system
is certified to the
ISO 9001:2008 standard

PROUDLY MADE IN ITALY

D.T.S. products are designed
and manufactured at the D.T.S.
plants in italy

0517I195

D.T.S. Illuminazione s.r.l. – Via Fagnano Selve 10-12-14 47843
Misano Adriatico (RN) Italia
Tel.: +39 0541 611131. Fax + 39 0541 611111
info@dts-lighting.it www.dts-lighting.it